

Thank you for choosing the

Magnetic Wireless Powerbank 5,000

WHAT'S INCLUDED:

- Magnetic Wireless Powerbank
- Recharging Cable



MAGNETICALLY ATTACHES



Unlike most magnetic wireless charges that only deliver 5-watts of power, this unit delivers 7.5-watts of wireless power; the most currently allowed under Apple guidelines for a magnetic portable charger. Your iPhone charges from 0-50% 33% faster; 30 minutes faster to full charge.

MAGSAFE COMPATIBILITY

Magnetically connects to iPhone 12 or newer (without case) or to any MagSafe-certified case. Will not magnetically attach to standard case.

The wireless powerbank maintains compatibility with Qi charging, so it can be used to wirelessly charge the iPhone 8 or later, as well as AirPods models with a wirelessly charging case as you would with any Qi certified charger.

RECHARGING THE MAGNETIC WIRELESS POWERBANK 5,000

Plug the supplied USB-C cable into the charge port and the other end into a UL approved power source/adaptor. Charging will begin immediately and LED will begin flashing.

3 ways to recharge: From wall outlet, car, computer



LED INDICATORS

Press power button to see battery level



CHARGING YOUR IPHONE 12 OR NEWER

- Place Wireless Powerbank below the iPhone camera and the integrated magnets will instantly align and connect your iPhone.
- Press the power button then charging should automatically begin.

Note: For best results, the Wireless Powerbank should be paired with an iPhone directly or an iPhone with MagSafe compatibility case.

CHARGING ANOTHER DEVICE

The USB-C port isn't just for recharging. You can also charge another device with this port at the same time your wireless iPhone charges.



USB-C Port

WARRANTY INFORMATION: At myCharge, we're dedicated to making the highest quality products possible. In that, we provide a one-year limited warranty from the date of purchase. Keep a copy of your receipt as proof of purchase and register your products at mycharge.com and check for the latest product updates as they develop. Failure to register your product and/or to provide proof of purchase may void the warranty. Warranty instructions and information visit: mycharge.com/warranty and select your model.

MYCHARGE SUPPORT: support.mycharge.com

WARNING: Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which myCharge is not responsible.

1. Do not expose battery to heat sources, extended direct sunlight or other high-temperature environments.
2. Avoid drops and excessive impacts to the battery.
3. Do not disassemble, attempt to repair or replace any part of the housing or battery.
4. Do not attempt to charge the battery using any other method, apparatus, or connections other than the device's charging cable.
5. Never dispose of batteries in the garbage. This is unlawful under state and federal environmental laws and regulation. Always take used batteries to your local battery-recycling center.

FCC COMPLIANCE WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: Changes or modifications not expressly approved by myCharge could void the user's authority to operate this equipment.