myEharge



myCharge name and logo are registered trademarks of RFA Brands. ©2012-2013 RFA Brands. All Rights Reserved. Patent Pending.

Made in China. IB-RFAM0229

OWNER'S MANUAL

For latest instructions please go to www.mycharge.com/instructions


Thank you for choosing myCharge Hub 6000™

Thanks for choosing myCharge.

Visit mycharge.com/videos/Hub to view the product demo video!

In The Box

- myCharge Hub 6000™
- Owner's manual



Section I: Quick Start

- 1. Charge up your Hub 6000 by using the fold-out prongs on the back of the unit for fast-charging via wall outlet.
- 2. As Hub 6000 charges, the battery icon will flash the color of the battery level. When the unit is fully charged, the battery icon will turn solid green. Press the level check button to see how much power is available.
- 3. Hub 6000 comes equipped with Apple Lightning and Micro-USB connectors, as well as a built-in USB port for use with your own cable. Connect your device(s) to one of the various inputs available. Charge up to three devices simultaneously by using all connectors and USB port.

- When charging through the Apple Lightning connector or USB port, you must press and hold the Hub 6000 power <u>button for 3 seconds</u> to begin charging if the Hub is not already turned on.
- 5. Unplug your device when it's charged, and go! Your Hub 6000 will automatically power off after your devices are unplugged.

Section II: Charging Hub 6000

To charge your Hub, simply plug the fold-out wall prongs into a wall outlet. You can expect a full charge from the wall in about three hours.

As your Hub charges, the battery icon will flash according to the energy level:

Solid Green: 100% Flashing Green: 71-99% Flashing Yellow: 41-70% Flashing Red: 0-40% Charge from the wall

Note: It is normal for your Hub 6000 to be warm to the touch while in use.

Section III: Charging Devices

Hub 6000 uses an automatic device detection system for the micro USB. When devices are plugged in, Hub 6000 provides charging power until they are unplugged or the Hub 6000 runs out of energy. When charging devices through the **Apple Lightning connector or USB port, if the Hub 6000 isn't already turned on, <u>press and hold</u> <u>the battery icon button for 3 seconds</u> to begin charging.**

Up to three devices can be charged simultaneously. The Hub 6000 Apple Lightning connector is compatible with iPhone 5 and any other devices with a Lightning connector. The Micro-USB connector and USB ports support the majority of mobile devices including smartphones, tablets, Bluetooth headsets, portable navigation devices, MP3 players, and more.

Section IV: Checking Battery Level

To check how much energy is available, press the battery level check button. The battery icon will illuminate accordingly:

Green: 71-100% Yellow: 41-70% Red: 11-40% Flashing Red: 0-10%

After 5 seconds, the LED will turn off.

Section V: Maintenance

To keep your Hub operating at its full potential, please do the following:

- 1. Re-charge every three months when not in use.
- 2. Keep dry and away from moist and corrosive materials.
- 3. To clean, wipe surface with dry cloth.

Section VI: Product Specifications

Battery: 22.3Wh Lithium Ion

Input:

AC: 100-240 VAC 50/60 Hz

Output:

Apple connector output: 5VDC, 2.1A Micro-USB output: 5VDC, 500mA USB output: 5VDC, 1.0A

5VDC, 3.6A Max Total

Section VII: Troubleshooting

My device is not charging: Confirm that your device is properly connected to the appropriate connector and the Hub itself has energy (by pressing the battery icon button). If the battery icon is red, there isn't enough energy to charge your devices – please recharge. If multiple devices are connected, disconnect them and connect only the device that is not charging.

For additional troubleshooting information and device compatibility, please visit: **www.mycharge.com**

ONE YEAR LIMITED WARRANTY

RFA BRANDS sells its products with the intent that they are free of defects in manufacture and workmanship for a period of one year from the date of original purchase, except as noted below. RFA BRANDS warrants that its products will be free of defects in material and workmanship under normal use and service. This warranty extends only to consumers and does not extend to Retailers.

To obtain warranty service on your RFA BRANDS PRODUCT, contact a Consumer Relations Representative by telephone at 1-888-251-2026 for assistance. Please make sure to have the model number and serial number of the product available.

RFA BRANDS does not authorize anyone, including, but not limited to, Retailers, the subsequent consumer purchaser of the product from a Retailer or remote purchasers, to obligate RFA BRANDS in any way beyond the terms set forth herein. This warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair; or any other conditions whatsoever that are beyond the control of RFA BRANDS.

This warranty is effective only if the product is purchased and operated in the country in which the product is purchased. A product that requires modifications or adoption to enable it to operate in any other country than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under this warranty.

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY. RFA BRANDS SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS WARRANTY REQUIRE MORE THAN THE REPAIR OR REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY.

NO REFUNDS WILL BE GIVEN. IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, RFA BRANDS RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS IN LIEU OF REPAIR OR REPLACEMENT.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of MYCHARGE.

This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state. Because of individual regulations, some of the above limitations and exclusions may not apply to you. For more information regarding our product line in the USA, please visit: **www.mycharge.com**

myCharge Service Center

Telephone: (888) 251-2026 Hours: 24/7 E-mail: cservice@mycharge.com

WARNINGS

Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which RFA BRANDS is not responsible.

- Do not store battery in high temperature environment, including intense sunlight or heat. Do not place battery in fire or other excessively hot environments.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this battery. If there is any damage to the battery such as dents, punctures, tears, deformities or corrosion, due to any cause, discontinue use and contact the manufacturer or dispose of it in an appropriate manner.

- 3. Do not disassemble the battery or attempt to repair or modify it in any manner.
- 4. Do not expose this battery to moisture or submerge it in liquid. Keep battery dry at all times.
- 5. Do not attempt to charge battery using any other method, apparatus, or connections other than the device's USB connector or wall prongs. For directions on the various ways to charge your myCharge product please refer to the owner's manual.
- 6. Do not attempt to replace any part of the battery.
- If this battery is intended by the Purchaser to be used by a minor, purchasing adult agrees to provide detailed instructions and warnings to any minor prior to use.
 Failure to do so is the sole responsibility of the purchaser, who agrees to indemnify the Manufacturer for any unintended use or misuse by a minor.
- 8. All batteries have gone through a thorough quality assurance inspection. If you find that your battery is excessively hot, deformed, cut, emitting odor, experiencing or demonstrating an abnormal phenomenon, immediately stop all battery use and contact the manufacturer.
- 9. For extended storage, first fully charge your battery.

10. Never dispose of batteries in the garbage. This is unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery-recycling center.

Note: The Manufacturer is not responsible for any damages one may suffer as a result of use, intended or unintended, or misuse of this battery in conjunction with any device or accessory other than the appropriate entertainment device for which this battery is designed.

FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

myCharge Service Center Telephone: (888) 251-2026 Hours: 24/7 E-mail: cservice@mycharge.com